



TAKE-A-LABEL

Operations Manual TAL-400R

Rewinder



MACHINE STARTUP

1. Slide core (Not Supplied) onto rewind shaft.
2. Using tape, attach labels to the top or "12 o'clock position" on a 3" core.
3. Rotate rewind shaft 2-3 turns.
4. Ensure that the Rewinder is square with printer.
5. Turn Rewinder on.

NOTE: Always load the Rewinder in the OFF position.

TO ADJUST REWIND SPEED AND TORQUE

1. Turn knob to increase or decrease speed.

